Lexmark MS510 & MS610 Series

Machine Type 4514-630, -635, -636

Service Manual

- Start diagnostics
- Maintenance
- Safety and notices
- Trademarks
- Index

October 17, 2012 **www.lexmark.com**

P/N 12G2826

Product information

Product name:

Lexmark MS510 and MS610 Series

Machine type:

4514

Model(s):

630, 635, 636

Edition notice

October 17, 2012

The following paragraph does not apply to any country where such provisions are inconsistent with local law: LEXMARK INTERNATIONAL, INC., PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions; therefore, this statement may not apply to you.

This publication could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in later editions. Improvements or changes in the products or the programs described may be made at any time.

References in this publication to products, programs, or services do not imply that the manufacturer intends to make these available in all countries in which it operates. Any reference to a product, program, or service is not intended to state or imply that only that product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any existing intellectual property right may be used instead. Evaluation and verification of operation in conjunction with other products, programs, or services, except those expressly designated by the manufacturer, are the user's responsibility.

Trademarks

Lexmark and Lexmark with diamond design are trademarks of Lexmark International, Inc., registered in the United States and/or other countries.

PrintCryption is a trademark of Lexmark International, Inc.

Mac and the Mac logo are trademarks of Apple Inc., registered in the U.S. and other countries.

PCL® is a registered trademark of the Hewlett-Packard Company. PCL is Hewlett-Packard Company's designation of a set of printer commands (language) and functions included in its printer products. This printer is intended to be compatible with the PCL language. This means the printer recognizes PCL commands used in various application programs, and that the printer emulates the functions corresponding to the commands.

All other trademarks are the property of their respective owners.

© 2012 Lexmark International, Inc.

All rights reserved.

P/N 12G2826

Table of contents

Product information....2

Edition notice....2

Notices and safety information....11

Laser notices....11

Safety....14

Preface....19

Service manual conventions....19

General information....21

Media guidelines....21

Paper guidelines....21

Using recycled paper and other office papers....23

Using specialty media....24

Supported paper sizes, types, and weights....26

Data security notice....28

Tools required for service....29

Diagnostic information....31

Troubleshooting overview....31

Performing the initial troubleshooting check....31

Power-on Reset (POR) sequence....31

Understanding the printer messages....32

Cartridge, imaging unit mismatch [41.xy]....32

Cartridge low [88.xy]....32

Cartridge nearly low [88.xy]....32

Cartridge very low, [x] estimated pages remain [88.xy]....32

Change [paper source] to [custom type name] load [orientation]....33

Change [paper source] to [custom string] load [paper orientation]....33

Change [paper source] to [paper size] load [orientation]....33

Change [paper source] to [paper type] [paper size] load [orientation]....33

Close front door....33

Complex page, some data may not have printed [39]....34

Configuration change, some held jobs were not restored [57]....34

Defective flash detected [51]....34

Error reading USB drive. Remove USB.....34

Error reading USB hub. Remove hub.....34

Imaging unit low [84.xy] 34
Imaging unit nearly low [84.xy] 35
Imaging unit very low, [x] estimated pages remain [84.xy] 35
Incorrect paper size, open [paper source] [34] 35
Insert Tray [x] 35
Insufficient memory to support Resource Save feature [35] 35
Insufficient memory to collate job [37] 35
Insufficient memory for Flash Memory Defragment operation [37] 36
Insufficient memory, some Held Jobs were deleted [37] 36
Insufficient memory, some held jobs will not be restored [37] 36
Load [paper source] with [custom string] [paper orientation] 36
Load [paper source] with [custom type name] [paper orientation] 36
Load [paper source] with [paper size] [paper orientation] 37
Load [paper source] with [paper type] [paper size] [paper orientation] 37
Load manual feeder with [custom type name] [paper orientation] 37
Load manual feeder with [custom string] [paper orientation] 37
Load manual feeder with [paper size] [paper orientation] 38
Load manual feeder with [paper type] [paper size] [paper orientation] 38
Maintenance kit low [80.xy] 38
Maintenance kit nearly low [80.xy] 38
Maintenance kit very low, [x] estimated pages remain [80.xy] 38
Memory full [38] 39
Network [x] software error [54] 39
Non-Lexmark [supply type], see User's Guide [33.xy] 39
Not enough free space in flash memory for resources [52] 40
Printer had to restart. Last job may be incomplete. 40
Reinstall missing or unresponsive cartridge [31.xy] 40
Reinstall missing or unresponsive imaging unit [31.xy] 40
Remove paper from standard output bin 40
Replace cartridge, 0 estimated pages remain [88.xy] 41
Replace cartridge, printer region mismatch [42.xy] 41
Replace imaging unit, 0 estimated pages remain [84.xy] 41
Replace maintenance kit, 0 estimated pages remain [80.xy] 41
Replace unsupported cartridge [32.xy] 42
Replace unsupported imaging unit [32.xy] 42
Serial option [x] error [54] 42
SMTP server not set up. Contact system administrator. 42
Standard network software error [54] 42
Standard parallel port disabled [56] 43
Standard USB port disabled [56] 43
Too many flash options installed [58] 43
Too many trays attached [58] 43
Unformatted flash detected [53] 44
Unsupported option in slot [x] [55] 44
Weblink server not set up. Contact system administrator. 44

Fixing print quality issues....44
Initial print quality check....44
Print quality checks....45
Paper jams....53
Avoiding jams....53
Understanding jam messages and locations....54
200 paper jams....56
201 paper jams....63
202 paper jams....64
230 paper jams....67
240 paper jams....70
250 paper jams....79
User attendance messages (0–99.99)....82
User attendance messages (0-99.99)....82
Toner cartridge smart chip contact service check....84
Imaging unit smart chip contact service check....85
Media size mismatch service check....85
Printer/cartridge mismatch service check....86
Insufficient memory service check....87
Printer hardware errors....88
1xx error messages....88
111.xx LSU service check....91
Fuser service check....91
LVPS service check....92
Toner density sensor service check....92
CTLS service check....93
Main drive gearbox service check....93
ACM service check....94
Cartridge gearbox service check....94
Tray 1 pick/lift motor gearbox service check....95
171.xx Cooling fan service check....95
9xx error messages....96
System software error service check....99
NVRAM mismatch failure service check....103
Input option hardware errors....105
3xx error messages....105
Option tray pick/lift motor service check....106
Option tray separator/passthrough motor service check....107
Option tray ACM motor service check....107
Option tray controller card service check....108
Symptoms....108
Base printer symptoms....108
Dead machine service check....109

Controller board service check 109
Control panel button service check 110
Control panel service check 111
Toner starvation service check 111
USB print service check 112
Network service check 113

Service menus 117

Understanding the control panel and menus (MS510dn and MS610dn) 117
Using the printer control panel 117
Understanding the colors of the indicator and Sleep button lights 118
Understanding the control panel and menus (MS610de) 119
Using the printer control panel 119
Understanding the colors of the indicator and Sleep button lights 119
Understanding the home screen 120
Using the touch-screen buttons 121
Menus list 123
Diagnostics menu 123
Entering the Diagnostics menu 123
Registration 124
Print Tests 124
Print Quality Pages 125
Hardware Tests 125
Duplex Tests 127
Input tray tests 129
Output Bin Tests 129
Base Sensor Test 130
Device Tests 131
Printer Setup 132
EP Setup 133
Reports 135
Event Log 135
Exit Diags 136
Configuration menu 137
Entering the Configuration menu 137
Maintenance Counter Value 137
Reset Maintenance Counter 137
Print Quality Pages 138
Reports 138
Panel Menus 138
PPDS Emulation 138
Download Emuls 139
Factory Defaults 139

Energy Conserve 139
Paper Prompts 139
Envelope Prompts 140
Action for Prompts 140
Jobs on Disk 141
Disk Encryption 141
Erase All Information on Disk 141
Wipe All Settings 142
Font Density 142
Font Sharpening 142
Reduced Curl 142
Require Standby 142
A5 Loading 143
UI Automation 143
Key Repeat Initial Delay 143
Key Repeat Rate 144
Clear Supply Usage History 144
Clear Custom Status 144
USB Speed 144
Automatically Display Error Screens 144
USB PnP 145
Entering Invalid engine mode 145
Entering Recovery mode 145
Accessing the Network SE menu 146
Service Engineer menu 146
Accessing the service engineer (SE) menu 146
Service engineer (SE) menu 146

Repair information 147

Removal precautions 147
Data security notice 147
Handling ESD-sensitive parts 147
RIP board/operator panel replacement 148
eSF solutions backup 148
Ribbon cable connectors 149
Zero Insertion Force (ZIF) connectors 149
Horizontal top contact connector 150
Horizontal bottom contact connector 153
Vertical mount contact connector 156
Horizontal sliding contact connector 159
Low Insertion Force (LIF) connector 162
Printhead assembly adjustments 163
Removal procedures 166

Left side removals....166
Left cover removal....166
Main drive gearbox removal....167
MPF solenoid removal....169
MPF gearbox removal....171
Reverse solenoid removal....174
Cartridge gearbox removal....175
Duplex gear assembly removal....176
Right side removals....178
Right cover removal....178
Right cover removal (MS610de)....178
Tray present sensor removal....179
Cooling fan duct removal....180
Cooling fan removals....180
Cooling fan mount removal (MS610de)....182
Controller board shield removal (MS610de)....184
Controller board removals....184
Toner cartridge smart chip contact removal....188
Front removals....190
Left front mount removal....190
Right front mount removal....191
Transfer roll removal....193
Cartridge plunger removal....194
Bezel removals....197
Nameplate removals....199
Control panel assembly removals....201
UICC removals....205
Control panel USB port removal (MS610dn)....208
Speaker and control panel USB port removal (MS610de)....209
MPF assembly removal....210
MPF pick roller cover removal....213
MPF pick roller removal....213
Bail removal....214
Jam access cover removal....214
Front door removal....215
Front access cover removal....218
Front door sensor removal....218
Front input guide removal....219
Separator pad removal....221
Bottom removals....223
Power supply removals....223
Power supply removal....223
Power supply removal (MS610)....224
Power supply shield removal....225

Duplex removal....226
Duplex sensor and input sensor removal....227
Index sensor removal....230
Media present sensor removal....230
Toner density sensor removal....232
Trailing edge sensor removal....232
ACM assembly removal....233
Pick/Lift motor gearbox removal....239
Rear side removals....240
Dust cover removal....240
Rear door and cover removal....240
Narrow media/bin full sensor removal....241
Redrive assembly removal....243
Fuser removal....244
Top side removals....245
Top cover removal....245
Laser scanning unit (LSU) removal....246
250/550-sheet option tray removals....247
Pick roller removal....247
Separator roll assembly removal....248
ACM assembly removal....250

Component locations....253

Exterior locations....253
MS510dn and MS610dn exterior locations....253
MS610de exterior locations....255

Maintenance....257

Inspection guide....257
Scheduled maintenance....258
Maintenance kits....258
Resetting the maintenance counter....259
Lubrication specification....260
Cleaning the printer....260

Parts catalog....262

Legend....262
Assembly 1: Covers....263
Assembly 2: Electronics 1....267
Assembly 3: Electronics 2....269
Assembly 4: Frame....271

Assembly 5: Option trays....273
Assembly 6: Maintenance kits....275
Assembly 7: Power cords....277

Appendix A: Printer specifications....279

Product power consumption....279
Electrical specifications....279
Operating clearances....280
Acoustics....280
Operating environment....281

Appendix B: Options and features....283

Available internal options....283
Media handling options....283

Appendix C: Theory of operation....285

POR sequence....285
Printer control....285
Paper path information....285
Input tray....285
Multipurpose feeder (MPF)....286
Simplex printing....286
Duplex printing....287
Media handling components....287
Main drive gearbox....287
Autocompensator mechanism (ACM)....288
Key components....288
Sensors....288
Other key components....290
Electrophotographic process (EP process)....291

Appendix D: Acronyms....297

Acronyms....297

Index....299

Part number index....307

Part name index....311